

TOP STRIKE



Align with $\odot$ Rods $\frac{2-1/4}{(57)}$

$$\frac{1-5/16}{(33)}$$

CUT LINE

TAPE TO DOOR

TOP LATCH & STRIKE

1. Use with Installation Instructions FM 164A.
2. Mark Φ Rods line on door face. Note that the centerline of the rods and strikes used to install top and bottom bolts, is not the Vertical Reference centerline.
3. For ED5470 Series, Install Top Strike and Strike Angle Mounting Plate shown below.
4. For Less Bottom Rod (LBR) Devices M55 option, omit bottom latch and strike installation.
5. For Fire-Rated Less Bottom Rod SVR applications, refer to Popper Installation Instructions FM547.
6. Unreinforced frames require that 12-24 blind rivet nuts (by others) be used to bolt strike. Frames are considered not reinforced when strike mounting screws cannot engage (3) full threads.
7. Dimensions given in $\frac{\text{inches}}{(\text{mm})}$.
8. **CAUTION:** Office copiers and facsimile machines may change the size of a drawing and make the template inaccurate to use as a door marker. If this is not the original template packed with the device, use only the dimensions written on the template to locate the holes on the door (do not use the template as a door marker).



**Corbin
Russwin** 

In U.S.:
Corbin Russwin, Inc.
225 Episcopal Road
Berlin, CT 06037 USA
Phone: 860-225-7411 Fax: 860-828-7266

In Canada:
Yale-Corbin Canada LTD.
3160 Orlando Drive
Mississauga, Ontario, Canada L4V1R5
Phone: 905-672-6220 Fax: 905-672-9022

Top Strike and Strike Angle Mounting Plate for ED5470 (B) (F) Series Surface Vertical Rod Exit Devices