

CAMO® 5/16" Structural Series Screws

Installation Instructions

1 Installation

- 1.1 Installation shall comply with the approved construction documents, the manufacturer installation instructions, this TER and the applicable building code.
- 1.2 In the event of a conflict between the manufacturer installation instructions and this TER, the more restrictive shall govern.
- 1.3 Fasteners shall be installed with a 1/2" (12.7 mm), low rpm/high torque electric drill (450 rpm).
- 1.4 Fasteners shall be installed with manufacturer-supplied bits.
- 1.5 Fasteners shall be installed with the underside of the head flush to the surface of the wood member. Fasteners shall not be overdriven.
- 1.6 Fasteners shall not be struck with a hammer during installation.
- 1.7 Lead holes are not required but may be used where lumber is prone to splitting.
- 1.8 Installer shall use appropriate/required personal protection equipment during installation and must not place fastener in mouth.