## TABLE 402.4.2

## AIR BARRIER AND INSULATION INSPECTION COMPONENT CRITERIA

Project Name:	Sample Addition	
Street:	: 346 Main Street	
City, State, Zip:	Orlando , FL , 32922-	
Owner:	OWNER	
Design Location:	FL, Orlando	

Builder Name: BUILDER Permit Office: Permit Number: Jurisdiction:

COMPONENT	CRITERIA	
<b>COMPONENT</b> Air barrier and thermal barrier	CRITERIA   Exterior thermal envelope insulation for framed walls is installed in substantial contact and continuous alignment with building envelope air barrier.   Breaks or joints in the air barrier are filled or repaired.   Air-permeable insulation is not used as a sealing material.   Air-permeable insulation is inside of an air barrier.	CHECK
Ceiling/attic	Air barrier in any dropped ceiling/soffit is substantially aligned with insulation and any gaps are sealed. Attic access (except unvented attic), knee wall door, or drop down stair is sealed.	
Walls	Corners and headers are insulated. Junction of foundation and sill plate is sealed.	
Windows and doors	Space between window/door jambs and framing is sealed.	
Rim joists	Rim joists are insulated and include an air barrier.	
Floors (including above-garage and cantilevered floors)	Insulation is installed to maintain permanent contact with underside of subfloor decking.	
Crawl space walls	Insulation is permanently attached to walls. Exposed earth in unvented crawl spaces is covered with Class I	
Shafts, penetrations	Duct shafts, utility penetrations, knee walls and flue shafts opening to exterior or unconditioned space are sealed.	
Narrow cavities	Batts in narrow cavities are cut to fit, or narrow cavities are filled by sprayed/blown insulation.	
Garage separation	Air sealing is provided between the garage and conditioned spaces.	
Recessed lighting	Recessed light fixtures are air tight, IC rated, and sealed to drywall. Exception—fixtures in conditioned space.	
Plumbing and wiring	Insulation is placed between outside and pipes. Batt insulation is cut to fit around wiring and plumbing, or sprayed/blown insulation	
Shower/tub on exterior wall	Showers and tubs on exterior walls have insulation and an air barrier separating them from the exterior wall.	
Electrical/phone box on	Air barrier extends behind boxes or air sealed-type boxes are installed.	
Common wall	Air barrier is installed in common wall between dwelling units.	
HVAC register boots	HVAC register boots that penetrate building envelope are sealed to subfloor or drywall.	
Fireplace	Fireplace walls include an air barrier.	