

Force Engineering & Testing

19530 Ramblewood Drive
Humble, Texas 77338
Phone: (281) 540-6603 FAX: (281) 540-9966
Website: www.forceengineeringtesting.com

Product Evaluation Report
TRI COUNTY METALS

1" Nailstrip, 24 Ga. 16" Wide Roof Panel over 15/32" Plywood

Florida Product Approval # 4595.8 R5

Florida Building Code 2020

Per Rule 61G20-3

Method: 1 -D

Category: Roofing

Subcategory: Metal Roofing

Compliance Method: 61G20-3.005(1)(d)

NON HVHZ

Product Manufacturer:

Tri County Metals

301 S. E. 16th Street

Trenton, Florida 32693

Engineer Evaluator:

Johnathan Green, P.E. #88223

Florida Evaluation ANE ID: 12901

Validator:

Brian Jaks P.E. #70159


Contents:

Evaluation Report Pages 1 – 4



THIS ITEM HAS BEEN
DIGITALLY SIGNED AND
SEALED BY JOHNATHAN
GREEN ON THE DATE
ADJACENT TO THE SEAL.

PRINTED COPIES OF THIS
DOCUMENT ARE NOT
CONSIDERED SIGNED AND
SEALED AND THE
SIGNATURE MUST BE
VERIFIED ON ANY
ELECTRONIC COPIES.



Compliance Statement: The product as described in this report has demonstrated compliance with the Florida Building Code 2020, Sections 1504.3.2.

Product Description: 1" Nailstrip Roof Panel, 24 Ga. Steel, 16" Wide, Roof Panel attaching to 15/32" APA Plywood decking. Non-structural Application.

Panel Material/Standards: Material: 24 Ga. Steel conforming to Florida Building Code 2020 Section 1507.4.3
 Yield Strength: Min. 50.0 ksi
 Corrosion Resistance: Panel Material shall comply with Florida Building Code 2020, Section 1507.4.3

Panel Dimension(s): Thickness: 0.024"
 Width: 16" max coverage
 Female Rib: 1" tall
 Male Rib: ¾" tall rib w/ slotted strip.
 Panel Seam: Snap Lock

Panel Fastener: Through Panel Slot: (1) #10-13 x 1" GP Pancake Type A
 In Pan of Panel: (2) #10-11 x 1" Eclipse Head Type A
 ¼" minimum penetration through plywood
 Corrosion Resistance: Per Florida Building Code 2020, Section 1507.4.4.


Substrate Description: Min. 15/32" thick, APA Rated plywood over supports at maximum 24" O.C.
 Design of plywood and plywood supports are outside the scope of this evaluation. Substrate must be designed in accordance w/ Florida Building Code 2020.


Allowable Design Uplift Pressures:

Table "A"

| | | | |
|--|-----------|-----------|-----------|
| Maximum Total Uplift Design Pressure: | 59.75 psf | 101.0 psf | 153.5 psf |
| Panel Slot Fastener Spacing: | 16" O.C. | 6 ¾" O.C. | 6 ¾" O.C. |
| Panel Pan Fastener Spacing: | NA | NA | 12" O.C. |

*Design Pressure includes a Safety Factor = 2.0.


 OCT 13 2020




THIS ITEM HAS BEEN DIGITALLY SIGNED AND SEALED BY JOHNATHAN GREEN ON THE DATE ADJACENT TO THE SEAL.

PRINTED COPIES OF THIS DOCUMENT ARE NOT CONSIDERED SIGNED AND SEALED AND THE SIGNATURE MUST BE VERIFIED ON ANY ELECTRONIC COPIES.



- Code Compliance:** The product described herein has demonstrated compliance with The Florida Building Code 2020, Section 1504.3.2.
- Evaluation Report Scope:** The product evaluation is limited to compliance with the structural wind load requirements of the Florida Building Code 2020, as relates to Rule 61G20-3.
- Performance Standards:** The product described herein has demonstrated compliance with:
- UL 580-06 - Test for Uplift Resistance of Roof Assemblies
 - UL 1897-2012 - Uplift Test for Roof Covering Systems
 - TAS 100 - Test Procedure for Wind and Wind Driven Rain Resistance of Discontinuous Roof Systems
- Reference Data:**
1. UL 580-94 / 1897-98 Uplift Test
Force Engineering & Testing, Inc. (FBC Organization # TST-5328)
Report No. 72-0314T-06*, Dated 03/24/2007
 2. TAS 100-95
Farabaugh Engineering & Testing, Inc. (FBC Organization # TST-1654)
Report No. T158-07*, Dated 04/05/2007
 3. Certificate of Independence
By Johnathan Green, P.E. (No. 88223) @ Force Engineering & Testing
(FBC Organization # ANE ID: 12901)
- Test Standard Equivalency:**
1. The UL 580-94 test standard is equivalent to the UL 580-06 test standard.
 2. The UL 1897-98 test standard is equivalent to the UL 1897-2012 test standard.
- Quality Assurance Entity:** The manufacturer has established compliance of roof panel products in accordance with the Florida Product Code and Rule 61G20-3.005 (3) for manufacturing under a quality assurance program audited by an approved quality assurance entity.




THIS ITEM HAS BEEN
DIGITALLY SIGNED AND
SEALED BY JOHNATHAN
GREEN ON THE DATE
ADJACENT TO THE SEAL.

PRINTED COPIES OF THIS
DOCUMENT ARE NOT
CONSIDERED SIGNED AND
SEALED AND THE
SIGNATURE MUST BE
VERIFIED ON ANY
ELECTRONIC COPIES.



- Minimum Slope Range:** Minimum Slope shall comply with Florida Building Code 2020, including Sections 1507.4.2 and in accordance with Manufacturers recommendations.
- Installation:** Install per manufacturer's recommended details.
- Underlayment:** Self-adhered roofing underlayment minimum 40 mil thickness. Per Florida Building Code 2020, Section 1507.1.1 and manufacturer's installation guidelines.
- Roof Panel Fire Classification:** Fire classification is not part of this acceptance.
- Shear Diaphragm:** Shear diaphragm values are outside the scope of this report.
- Design Procedure:** Based on the dimensions of the structure, appropriate wind loads are determined using Chapter 16 of the Florida Building Code 2020 for roof cladding wind loads. These component wind loads for roof cladding are compared to the allowable pressure listed above. The design professional shall select the appropriate erection details to reference in his drawings for proper fastener attachment to his structure and analyze the panel fasteners for pullout and pullover. Support framing must be in compliance with Florida Building Code 2020 Chapter 22 for steel, Chapter 23 for wood and Chapter 16 for structural loading.

*The Test Reports are owned by Metalforming, Inc. Metalforming, Inc. gives the above manufacturer permission to use these test reports.




THIS ITEM HAS BEEN
DIGITALLY SIGNED AND
SEALED BY JOHNATHAN
GREEN ON THE DATE
ADJACENT TO THE SEAL.

PRINTED COPIES OF THIS
DOCUMENT ARE NOT
CONSIDERED SIGNED AND
SEALED AND THE
SIGNATURE MUST BE
VERIFIED ON ANY
ELECTRONIC COPIES.



Force Engineering & Testing
 19530 Ramblewood Drive
 Humble, Texas 77338
 Phone: (281) 540-6603 FAX: (281) 540-9966
 Website: www.forceengineeringtesting.com




OCT 13 2020

FL# 4595.8 R5

THIS ITEM HAS BEEN
 DIGITALLY SIGNED AND
 SEALED BY JOHNATHAN
 GREEN ON THE DATE
 ADJACENT TO THE SEAL.

PRINTED COPIES OF THIS
 DOCUMENT ARE NOT
 CONSIDERED SIGNED AND
 SEALED AND THE
 SIGNATURE MUST BE
 VERIFIED ON ANY
 ELECTRONIC COPIES.



Force Engineering & Testing


19530 Ramblewood Drive

Humble, Texas 77338


Phone: (281) 540-6603 FAX: (281) 540-9966

Website: www.forceengineeringtesting.com


TYPE 1 FASTENER PATTERN (SEE LOAD TABLE)



TYPE 2 FASTENER PATTERN (SEE LOAD TABLE)




OCT 13 2020



THIS ITEM HAS BEEN
DIGITALLY SIGNED AND
SEALED BY JOHNATHAN
GREEN ON THE DATE
ADJACENT TO THE SEAL.

PRINTED COPIES OF THIS
DOCUMENT ARE NOT
CONSIDERED SIGNED AND
SEALED AND THE
SIGNATURE MUST BE
VERIFIED ON ANY
ELECTRONIC COPIES.

FL# 4595.8 R5




Force Engineering & Testing

19530 Ramblewood Drive


Humble, Texas 77338

Phone: (281) 540-6603 FAX: (281) 540-9966

Website: www.forceengineeringtesting.com




OCT 13 2020



THIS ITEM HAS BEEN
DIGITALLY SIGNED AND
SEALED BY JOHNATHAN
GREEN ON THE DATE
ADJACENT TO THE SEAL.

PRINTED COPIES OF THIS
DOCUMENT ARE NOT
CONSIDERED SIGNED AND
SEALED AND THE
SIGNATURE MUST BE
VERIFIED ON ANY
ELECTRONIC COPIES.

FL# 4595.8 R5



Force Engineering & Testing

19530 Ramblewood Drive



Humble, Texas 77338

Phone: (281) 540-6603 FAX: (281) 540-9966

Website: www.forceengineeringtesting.com

HIGH PROFILE RAKE

- 1.) Turn cut edge of panel up 1".
- 2.) Determine location off zee closure. Apply sealant tape to flat of panel.
- 3.) Place closure on top of sealant tape. Secure through tape and panel with #10-12 x 1" HWH wood screws @ 12"oc.
- 4.) Apply a continuous strip of sealant tape to the top of the zee closure. Seal between ends of tape with butyl sealant.
- 5.) Install panels so that the field cut end is engaged into the open hem of the receiver trim, and fully embedded into the urethane sealant.
- 6.) Install the rake trim. Secure to closure zee with 1/4-14 x 7/8" HWH Tek/1 fasteners at 12"oc.




OCT 13 2020

THIS ITEM HAS BEEN
DIGITALLY SIGNED AND
SEALED BY JOHNATHAN
GREEN ON THE DATE
ADJACENT TO THE SEAL.

PRINTED COPIES OF THIS
DOCUMENT ARE NOT
CONSIDERED SIGNED AND
SEALED AND THE
SIGNATURE MUST BE
VERIFIED ON ANY
ELECTRONIC COPIES.

FL# 4595.8 R5





Force Engineering & Testing

19530 Ramblewood Drive

Humble, Texas 77338

Phone: (281) 540-6603 FAX: (281) 540-9966

Website: www.forceengineeringtesting.com



OCT 13 2020

THIS ITEM HAS BEEN
DIGITALLY SIGNED AND
SEALED BY JOHNATHAN
GREEN ON THE DATE
ADJACENT TO THE SEAL.

PRINTED COPIES OF THIS
DOCUMENT ARE NOT
CONSIDERED SIGNED AND
SEALED AND THE
SIGNATURE MUST BE
VERIFIED ON ANY
ELECTRONIC COPIES.

FL# 4595.8 R5



Force Engineering & Testing

19530 Ramblewood Drive



Humble, Texas 77338

Phone: (281) 540-6603 FAX: (281) 540-9966

Website: www.forceengineeringtesting.com

LOW EAVE

- 1.) Temporarily attach eave trim at ends w/ #10-12 x 1" pancake head wood screws
- 2.) Apply butyl sealant across top of eave trim as shown.
- 3.) Attach cleat through sealant w/ #10-12 x 1" pancake head wood screws @ 4"oc.
- 4.) Apply a second bead of butyl sealant across the top of the cleat, and over the fastener heads.
- 5.) Install panels so that the cleat is engaged into the field applied hem.




OCT 13 2020

THIS ITEM HAS BEEN
DIGITALLY SIGNED AND
SEALED BY JOHNATHAN
GREEN ON THE DATE
ADJACENT TO THE SEAL.

PRINTED COPIES OF THIS
DOCUMENT ARE NOT
CONSIDERED SIGNED AND
SEALED AND THE
SIGNATURE MUST BE
VERIFIED ON ANY
ELECTRONIC COPIES.

FL# 4595.8 R5



Force Engineering & Testing

19530 Ramblewood Drive



Humble, Texas 77338

Phone: (281) 540-6603 FAX: (281) 540-9966

Website: www.forceengineeringtesting.com

RIDGE / HIP

- 1.) Determine location of zee closure. Apply sealant tape to flat of panel.
- 2.) Place closure on top of sealant tape. Secure through tape and panel with #9-16 x 1" HWH wood screws @ 4"oc. Seal the tab of the closure to the side joints with butyl sealant.
- 3.) Apply a continuous strip of sealant tape to the top of the zee closure. Seal between ends of tape with butyl sealant.
- 4.) Install the ridge trim. Secure to closure zee with 1/4-14 x 7/8" HWH Tek/1 fasteners at 12"oc.



OCT 13 2020

THIS ITEM HAS BEEN
DIGITALLY SIGNED AND
SEALED BY JOHNATHAN
GREEN ON THE DATE
ADJACENT TO THE SEAL.

PRINTED COPIES OF THIS
DOCUMENT ARE NOT
CONSIDERED SIGNED AND
SEALED AND THE
SIGNATURE MUST BE
VERIFIED ON ANY
ELECTRONIC COPIES.

FL# 4595.8 R5